

Product Data Sheet

SORB[®]XT Safety-Kit

Article	SORB [®] XT Safety-Kit
Article No.	100500EN
Sachet (mm)	310x210x70
Pillow (mm)	300x200x50
Weight	0,70 Kg
Absorption capacity	2,60 L



Product Information:

Recommended use

- 2L sachet: Mobile first aid for smaller leakages
- Barrier pillow: On usual grounds and on water as a barrier and absorbent

Application

- Spread out SORB[®]XT evenly over the leaked substance and work into the material
- Place the pillows directly on the area of contamination and wait until it has reached its full absorptive capacity (the pillow will be entirely in the color of contaminated material)
- The pillow can be applied on all mentioned fields plus on water surfaces

Storage

- Store in an dry place with low humidity to avoid mold

After application

- Skim off or sweep up the substance from the surface
- Collect the substance with pick-up spatula and put it into a disposal bag/ collect the pillow with single-use gloves and put it into a disposal bag
- Dispose of the contaminated material following the respective valid laws and local regulations

Properties

- Ideal combination for small leakages, contains the following:
- 1x 2L Sachet of 100% organic SORB[®]XT fibre
- 1x Barrier pillow (filled with 100% organic SORB[®]XT fibre)
- 1x Single-use gloves
- 2x Disposal bag
- 1x Pick-up spatula